



1 INSTALLATION



2 INTERFACE CONNECTOR



Note: Connector interface is subject to model's specifications

Quick Start

① INSTALLATION

1. Power cord
2. USB Cable
3. HDMI Cable
4. DVI Cable
5. VGA Cable
6. VGA to Component/HDTV Adapter
7. 3 RCA Component Cable
8. Audio Cable Jack/Jack
9. S-Video Cable
10. Composite Video Cable
11. RS232 Cable
12. SPDIF Cable
13. Audio Cable Jack/RCA
14. LAN Cable
15. Audio cable jack for wired remote
16. 12V DC Cable
17. Mouse
18. USB disk/stick

Note: Connector interface is subject to model's specifications

② INTERFACE CONNECTOR

Connecting to a Computer

1. Ensure the projector and your computer are turned off.
2. Connect one end of the VGA cable to the "VGA IN" connector on the projector; connect the other end to the VGA connector on the computer and tighten the screws.
3. Connect one end of the power cord into the AC power socket on the projector; connect the other end to an electrical outlet.

Powering On the Projector

1. Remove the lens cap.
2. Turn on the projector first and then the computer.
3. Adjust the position, focus and zoom.
4. Run your presentation.

Powering Off the Projector

1. Press the power button twice.
2. Do not remove AC power cord from outlet until the projector fan shut down.

SCHELLSTART

① INSTALLATION

1. Netzkabel
2. USB-Kabel
3. HDMI-Kabel
4. DVI-Kabel
5. VGA-Kabel
6. VGA-auf-Component/HDTV-Adapter
7. 3 RCA Component-Kabel
8. Audiokabel Buchse/Buchse
9. S-Video Kabel
10. Composite Video-Kabel
11. RS232-Kabel
12. SPDIF-Kabel
13. Audiokabel mit Cinch-Anschluss
14. LAN-Kabel
15. Audiokabelanschluss für die verdrahtete Fernbedienung
16. 12VDC-Kabel
17. Maus
18. USB-Disk/-Stick

Hinweis: Die Anschlusschnittstelle variiert je nach dem Modell

② SCHNITTSTELLEN-ANSCHLUSS

Anschließen an einen computer

1. Gehen Sie sicher, dass Projektor und Computer ausgeschaltet sind.
2. Schließen Sie das eine Ende des VGA-Kabels an den „VGA IN“-Anschluss des Projektors an und das andere Ende an den VGA-Anschluss des Computers. Ziehen Sie die Schrauben fest.
3. Schließen Sie das eine Ende des Netzkabels an den Netzanschluss des Projektors und das andere Ende an eine Netzsteckdose an.

Einschalten des Projektors

1. Entfernen Sie die Objektivkappe.
2. Schalten Sie erst den Projektor und dann den Rechner ein.
3. Passen Sie die Position, die Schärfe und den Zoom an.
4. Beginnen Sie mit Ihrer Präsentation.

Ausschalten des Projektors

1. Drücken Sie zweimal auf die Ein/Aus-Taste.
2. Trennen Sie erst dann das Netzkabel von der Netzsteckdose, wenn der Ventilator des Projektors ausgeschaltet wurde.